

# Oxygen Pro Mini:

**Latest Firmware/Feature Version:** 2.15

**Latest Firmware/Feature Updater Application:** Windows: v1.0.2, macOS: 1.0.2

**Release Date:** July 13, 2021

## Minimum System Requirements

- Windows 8.1 or later (32- or 64-bit)
- macOS 10.13.6 or later
- Host USB 2.0 port

## Firmware/Feature Update Instructions

### Windows Update Instructions

**IMPORTANT:** Close all open applications on the computer you will be using to perform the update.

**IMPORTANT:** Use the Oxygen Pro Mini Preset Editor to backup and save any Presets or DAW presets you've created. This update will revert your Oxygen Pro Mini to its factory settings

1. On your Oxygen Pro Mini keyboard, press and hold the **Encoder Button**, and while continuing to press and hold the button, connect your Oxygen Pro Mini to an available USB port, powering on the Oxygen Pro Mini.
  - **Notice:** Your Oxygen Pro Mini will now display “Ready to update” on its screen.
2. Double-click the **Install M-Audio Oxygen Pro Mini Firmware Updater For Firmware 2.15 (Updater 1.0.2)**. A Windows prompt may appear asking if you trust this application to make changes to your device. Select **Yes**. Wait for C++ to update (this may take several minutes).
3. In the Updater window that appears, follow the on-screen instructions.
4. On your computer, click the **Start Menu** (Windows® icon), and select **Oxygen Pro Mini Firmware Updater**.
4. Click **Update Firmware** to start the update process, and then follow the on-screen instructions.
5. After the update is complete and the updater has confirmed that the update was successful, click “OK”
6. Disconnect your Oxygen Pro Mini keyboard from your computer
7. On your Oxygen Pro Mini keyboard press and hold the **Octave - and +** buttons, and while continuing to press and hold the buttons, connect your Oxygen Pro Mini keyboard to your computer

Congratulations—your Oxygen Pro Mini now has the latest Firmware!

## macOS Update Instructions

**IMPORTANT:** Close all open applications on the computer you will be using to perform the update.

**IMPORTANT:** Use the Oxygen Pro Mini Preset Editor to backup and save any Presets or DAW presets you've created. This update will revert your Oxygen Pro Mini to its factory settings

1. On your Oxygen Pro Mini keyboard press and hold the **Encoder Button**, and while continuing to press and hold the button, connect your Oxygen Pro Mini to an available USB port, powering on the Oxygen Pro Mini
  - **Notice:** Your Oxygen Pro Mini will now display “Ready to update” on its screen
2. Double-click the **M-Audio Oxygen Pro Mini Firmware Updater For Firmware 2.15 (Updater 1.0.2).dmg**.
3. Double-click the **M-Audio Oxygen Pro Mini Firmware Updater** app. A window may appear asking if you would like to open the application. Click “Open”.
4. Click **Update Firmware** to start the update process, and then follow the on-screen instructions.
5. After the updater confirms the update is successfully completed, click “OK”.
6. Disconnect your Oxygen Pro Mini keyboard from your computer.
7. On your Oxygen Pro Mini keyboard, press and hold the **Octave - and +** buttons, and while continuing to press and hold the buttons, connect your Oxygen Pro Mini keyboard to your computer.

Congratulations—your Oxygen Pro Mini now has the latest Firmware!

## Change History

### Changes Since 1.73

- Adds deeper integration with Ableton Live.
- Adds Preset Editor improvements.
- Improves Pitch and Mod wheel performance.
- Improved Timing Clock.
- Additional fixes and features added.

## Technical Support

For additional help, visit [m-audio.com/support](https://m-audio.com/support).